

BCM

GRC Limited

Unit 22, Civic Industrial Park,
Whitchurch, Shropshire,
SY13 1TT

Tel: 01948 665321
Fax: 01948 666381
E-mail: info@bcmgrc.com
Web: www.bcmgrc.com

Installation Details

Glassfibre Reinforced Headwalls. (Large)

BCM 900 Headwall

The following installation details are for standard products installed in good ground conditions.

1. Units should be bedded on a 200mm concrete base and mechanically fixed to the base.
2. Lifting positions are provided to aid installation. The use of a lifting or spreading beam is recommended for the BCM 900 Headwall.
3. Measure and mark the position and size of the hole required to accept the pipe entering the headwall.
4. Using a masonry drill, a series of holes are put into the headwall and then the centre “knocked out” of the hole.
5. The pipe should then be inserted into the headwall and fixed as required. Care should be taken that the pipe is fully supported by the bedding.
6. Once the base is secure the headwall is back filled with concrete level with the top of the unit. We would recommend that this is then benched at 45 degrees to give a neat appearance.
7. Topsoil or turf can then be placed around the headwall as required.

For poor ground conditions or non standard applications please contact our technical department on 01948 665321.